

USER INSTRUCTION FOR EYE PROTECTORS
(FLEXI VISION, FULL VISION, VISION 1, VISION 2, ECO 1, ECO 2)
according to EN 170:2003-01

The eye protector provides protection against ultraviolet and visible on UV equipments.

FIELD OF APPLICATION AND CONTRAINDICATIONS

This Individual Protective Equipment offers effective eye protection against UVA radiation emitted during artificial tanning sessions, complying with the specifications stated in the European regulation for this kind of IPE. It may be also be used when sunbathing both at the beach or the swimming pool. Considering the aim of these protectors, they are not designed for the user to carry out tasks when details are to be noticed.

ACCESSORIES, SPARE PARTS AND SHELF LIFE

The protector includes a piece for fastening: the silicone elastic band (ref. FLEXI VISION, FULL VISION, VISION 2, ECO 2) or a plastic transparent piece (ref. VISION 1, ECO 1). We recommend using the eye protector for a 1 year. The duration of use depends on factors such as use, cleaning, storage and maintenance. Frequently inspections and replacement if it is damaged or scratched are recommended.

INSTRUCTIONS FOR USE, STORAGE, MAINTENANCE, CLEANING AND DISINFECTION

In order to obtain adequate protection it is essential that the protector is properly adjusted to the facial anatomy. The protector must be securely fastened without excessive pressure. The protector must be placed in the position of use before exposing yourself to the source of radiation. No particular storage conditions are needed except for the essential hygiene conditions: clean and dry environment, away from heat and pollutants. When they are not being used, they are to be kept in the individual case or bag that will be provided to you for this purpose. They must be cleaned with some regularity, cleaning them with soapy water. Do not use either solvents or dirty cloths or dusters. For preventative reasons it is recommended that you do not share your protectors with others. In the event of a change of user, previous disinfection by using a clean cloth or duster and soapy water is to be carried out. Solvents and other products of similar characteristics are not to be used under any circumstances.

WARNING: None of the materials used in the protector's manufacture is known to cause irritation, skin irritability or allergy. In the case of these symptoms appearing in a particularly sensitive person, please inform the manufacturer.

SAFETY MARKING

EN 170 ENFAVI CE - Where EN 170 is the number of the standard, ENFAVI the manufacturer and CE, the certification mark. These UV protective goggles satisfy the requirements of (EU) Regulation 2016/425, the European Directive 2001/95/EC and the harmonized standard EN 170:2003-01.

VICEDO MARTI, S.L.
C/ Ávila, 2
03440 IBI - SPAIN
TEL. +34 965 554 708
export@lessiangiss.com

NOTIFIED BODY Nº 196
DIN CERTCO
Gesellschaft für Konformitätsbewertung mbH
Alboinstraße 56
12103 Berlin - Germany